



KONICA MINOLTA

Printing on Card Stocks — from MAC's

Make & Models:

Konica Minolta bizhub: INFO-Palette Series copiers (model numbers ending in 4, 4e, 7, 8, 8e, 9, & large MFP copier/printer **i-Series**).



What's It Do?

When printing on heavy weight paper or card stock, you must tell the device the correct weight to ensure proper print quality and to prevent jamming.

If you're making more than one trip to the copier, you're doing it wrong!

The most common error people make is to pre-load the bypass tray with the paper they want, yell out "NOBODY PRINT!", go back to their computers and select the bypass tray from the printer driver, without selecting the proper paper type at any step along the way. Use the steps below to properly set up, and print the job so as to require only one trip to the copier and not have any wasted paper in the recycle bin.

- ◆ The 1st step of printing on any card stock is determining what Thick setting to use. To determine the proper one, you need to look for the GSM or g/m² weight on the package. (See pictures to the right). Note: do not use the lb weight.


Use the chart on the reverse of this cheat sheet to determine which Thick setting you need.

- ◆ **INKJET Paper:** make sure your paper is made for Laser Printers and/or Copiers. InkJet paper is coated to absorb cold, liquid ink and will not allow toner to fuse to it.



When ready to Print:

- 1) Click File, Print (or **⌘ P**) to open the print dialogue box.
- 2) Click on the Paper Tray/ Output Tray tab. Select the Paper Type from the pull down menu. Leave the Paper Tray set to AUTO!
- 3) Select any other settings you wish, click Print and send to print.
- 4) At the device, WHEN PROMPTED, load the card stock in the Bypass tray. Note: Print side is down. This will only be an issue if the cardstock is gloss coated on one side only.



Tips & Tricks



When printing anything, the device will look for 2 things: the **SIZE**, and the **TYPE** of paper you have asked for. If either one of those two things does not match what is already loaded in the main trays (usually set to standard sizes, Plain paper type), then the device will automatically wait for you to load the paper in the bypass. This is why you don't need to pre-load your paper. This also minimizes the number of steps to print the job, and reduces opportunities for errors.



KONICA MINOLTA

Paper Weight Equivalencies - iSeries

Maximum paper weight: **300 g/m²** on iSeries: c250i - c750i and 300i - 950i devices
210 g/m² on iSeries: c3350i/c4050i, 4050i/4750i, c3351i/c4051i, 4051i/4751i



*Check paper packages to determine correct paper weight setting for the Konica Minolta devices. Use g/m² (or GSM) value.

